

11: GPS C/U
12: MAIN C/U
12A: TRANSMITTER
12B: MEMORY
40: BASE STATION
50: TIE-UP STATION
60: USER

11: GPS C/U
12: MAIN C/U
12A: TRANSMITTER
12B: MEMORY
40: BASE STATION
50: TIE-UP STATION
60: USER

FIG.2




FIG.3




FIG.4




FIG.5




FIG.6




FIG.7






FIG.9



09/980105 0222

FIG.10



09/980105 032202

FIG.11





FIG.12



09/980105 000000